PARTS CATALOGUE / TECHNICAL GUIDE Cal. 7N32C Cal. 7N33C Cal. 7N39C

[SPECIFICATIONS]

Cal. No.		7N32C	7N33C	7N39C	
Movement					
		Contraction of the second seco	A Contraction of the second se		
		The illustrations refer	to Cal. 7N33C.	(x 1.0)	
	Outside diameter	ø24.0 mm 21.5 mm between 12 o'clock and 6 o'clock sides 21.3 mm between 3 o'clock and 9 o'clock sides			
Movement size	Casing diameter	ø23.3 mm 21.5 mm between 12 o'clock and 6 o'clock sides 21.3 mm between 3 o'clock and 9 o'clock sides			
	Height	2.57 mm	2.78 mm	2.57 mm	
Time indication		3 hands		2 hands	
Driving system		Step motor (Load compensated driving pulse type)			
Additional mech	anism	Date calendar			
		Instant setting device for date calendar			
		_	Day calendar	_	
		_	Instant setting device for day calendar	_	
		Train wheel setting device _			
		Electronic circuit reset switch			
		Battery life indicator _			
Loss/gain		Monthly rate at normal temperature range: less than 15 seconds			
Regulation system		Nil			
Measuring gate by quartz tester		Use 10-second gate.			
Battery		SEIKO SR920SW, Maxell SR920SW, Sony SR920SW, Matsushita SR920SW, Eveready 371 Battery life is approximately 5 years. Voltage: 1.55V			
Jewels		1 jewel			

SEIKO CORPORATION

PARTS CATALOGUE

Cal. 7N32C, 7N33C, 7N39C



PARTS CATALOGUE

Remarks:

- (11) Hour wheel
- (18) Fourth wheel and pinion
- (33) Center wheel and pinion
- (36) Main plate

• Discrimination of the hand installation heights

Cal. 7N Series watches have numerals printed on the dial and the movement to indicate the hand installation heights. When repairing, refer to the table below.

Discrimi-	Height	Short type	Standard type	
nation	Numeral for discrimination	1	2	
Printed on		Dial	Movement	
		Ex) Standard type	Ex) Standard type	
Printed position		JAPAN 7N33-5A00 R2 The numeral is printed at the right end.	The numeral is printed below the calibre number.	

Combination:

* The hand installation heights can be discerned from the shape of the following parts. Refer to the table below.

[Cal. 7N32C]

Numeral for discrimination	Center wheel and pinion	Fourth wheel and pinion	Hour wheel	Main plate (Center pipe)
1			<u> </u>	
	0221 929	0241 929	0271 929	0100 941
2			Ē	<u> </u>
	0221 904	0241 904	0271 942	0100 942

PARTS CATALOGUE

Cal. 7N32C, 7N33C, 7N39C

[Cal. 7N33C]

[Cal. /1433C]				
Numeral for discrimination	Center wheel and pinion	Fourth wheel and pinion	Hour wheel	Main plate (Center pipe)
2				
	0221 934	0241 934	0271 934	0100 943

[Cal. 7N39C]

Numeral for discrimination	Center wheel and pinion	Fourth wheel and pinion	Hour wheel	Main plate (Center pipe)
1		<u> </u>	<u> </u>	
	0221 929	0241 940	0271 929	0100 941
2			<u> </u>	
	0221 904	0241 941	0271 942	0100 942

(15) Battery connection (+) 4268 620

Note: The battery connection (+) we are supplying has no calibre number nor numeral printed on it for discriminating the hand installation height.



(30) Winding stem 0351 892

The type of winding stem is determined based on the design of cases. Check the case number and refer to "SEIKO Casing Parts Catalogue" to choose a corresponding winding stem.

Cal. 7N32C, 7N33C, 7N39C

- The explanation here is only for the particular points of Cal. 7N32C, 7N33C and 7N39C.
- For the repairing, checking and measuring procedures, refer to the "TECHNICAL GUIDE, GENERAL INSTRUCTIONS".

I. STRUCTURE OF THE CIRCUIT BLOCK



Note:

Though Cal. 7N32C, 7N33C and 7N39C have the same circuit block pattern, Cal. 7N39C is not provided with the battery indicator function. The circuit block of Cal. 7N39C has an identification mark as shown below to distinguish it from the circuit blocks of Cal. 7N32C and 7N33C.



II. REMARKS ON DISASSEMBLING AND REASSEMBLING

Use the universal movement holder for disassembling and reassembling.

- (1) Hands
- How to install

When installing the hands, remove the battery and place the movement directly on a flat metal plate or the like.



(5) Intermediate wheel for day correction (only for Cal. 7N33C)

Set the intermediate wheel for day correction in the direction as shown in the illustration at right.



(6) Date dial guard

Unlike conventional movements, the date dial guard is not fixed with screws. It is set to the main plate with the three protrusions, which are caught under the main plate by turning the guard. Then, it is fixed by the two guide pins.

• How to remove

- Lightly lift the A portion of the date dial guard with tweezers to release it from the guide pin, and then move it in the counterclockwise direction until it gets on the guide pin.
- Release the B portion of the date dial guard in the same way as described above, and then move it in the counterclockwise direction until it gets on the guide pin.
- Check that all the three protrusions of the date dial guard have come off from the main plate, and then remove the date dial guard.



• How to install

- Put the date dial guard on the main plate so that the A and B portions are over the guide pins, as shown in the illustrations at right.
- Move the protrusion D of the date dial guard in the clockwise direction so that it is caught under the main plate.
- Slightly move the protrusions C and E in the clockwise direction alternately to set them under the main plate. Then, set the A and B portions of the date dial guard to the guide pins.
- Check that the date dial guard is fixed securely to the main plate.





for compensating for the heavy load that may be applied to the gear train, etc. In this case, overhaul and clean the movement parts and then measure current consumption for the whole movement again.