

# PARTS LIST

# CAL. Y432B

PART NO.	PART NAME	PART NO.	PART NAME
121 142	Center wheel bridge	4225 140	Battery clamp
131 145	Third wheel bridge	4239 140	Rotor stator
★224 141	Center wheel with cannon pinion	4242 142	Plus terminal of battery connection
★224 142	Center wheel with cannon pinion	4270 140	Battery connection
★224 143	Center wheel with cannon pinion	4446 140	Crystal unit cushion
231 140	Third wheel & pinion	011 541	Upper hole jewel for step rotor
241 140	Fourth wheel & pinion	011 541	Lower hole jewel for step rotor
261 140	Minute wheel	012 155	Dial screw
★271 141	Hour wheel	012 156	Center wheel bridge screw
★271 142	Hour wheel	012 157	Third wheel bridge screw
★271 143	Hour wheel	012 208	Setting lever spring screw
282 140	Clutch wheel	012 374	Battery clamp screw
351 142	Winding stem (14.10 mm)	012 460	Screw for circuit block insulator
383 140	Setting lever	012 461	Circuit block screw B
384 140	Yoke (clutch lever)	012 464	Circuit block screw A
387 140	Minute wheel bridge	012 777	Minute wheel bridge screw
388 140	Setting lever spring	017 146	Tube for center wheel bridge screw
391 140	Train wheel setting lever	017 147	Tube for third wheel bridge screw
490 140	Center wheel friction spring	017 148	Tube for setting lever
491 140	Dial washer	017 150	Tube for coil block
493 160	Hour wheel ring (Thickness 0.03 mm, gold)	017 151	Tube for circuit block A
493 161	Hour wheel ring (Thickness 0.05 mm, silver)	017 160	Tube for circuit block B
493 162	Hour wheel ring (Thickness 0.07 mm, gold)	MAXELL SR621SW	Battery
4001 142	Circuit block	SEIZAIKEN TR621SW	
4002 140	Coil block		
4146 140	Step rotor		
4216 147	Insulator for circuit block		

**Remarks:**

- ★ Center wheel with cannon pinion and Hour wheel.  
There are three different types as specified below.

Combination:

Type	Center wheel with cannon pinion	Hour wheel
a	★224 141	★271 141
b	★224 142	★271 142
c	★224 143	★271 143